

Frame Styles

Frame upgrades give your Wood Shutters a built-in look, and can help architecturally integrate them with your existing window frames or other wood detailing.

Bullnose Frames are smooth, rounded, and the most widely-used style in cabinetry, countertops and molding of modern homes.

Deco Frames add character and detailing; **Z Frames** are often used when windows aren't perfectly square. Your Installer will advise if your windows require this style.

1" Bullnose



2" Bullnose



2" Bullnose Z



2" Deco Frame



2" Deco Frame Z

